

MopMatic - the two systems explained...

The Mopmatic system of pre-prepared mopping is available as a stand alone module or an on trolley system.

MopMatic is a unique mop preparation system that allows operators to have an almost constant supply of clean, uniformly impregnated mops to carry out the task in hand. Whether the need is for cleaning or disinfecting or a combination of the two, uniformly prepared mops leave nothing to chance.

1 Load the mop box with 10 clean mop heads...



2 Pour the approved solution into the central automatic dispensing reservoir...



3

Close the lid and leave for 15 minutes.



4

Rotate the pail 180° and leave for 15 minutes.



5 Return pail to the lid up position, open lid and remove prepared mop.



6 After use place dirty mops in red bucket & replace lid.

Red bucket can hold approximately 20-25 dirty mops.



1 Load the mop box with 10 clean mop heads...



2 Pour the approved solution into the central automatic dispensing reservoir...



3

Close the lid and leave for 15 minutes.



4

Rotate the pail 180° and leave for 15 minutes.



5

Return pail to the lid up position, open lid and remove prepared mop.



6

After use place dirty mops in red bucket & replace lid.

Red bucket can hold approximately 20-25 dirty mops.

